



KU1500A Quick Reference Guide

Use KU1500A to make a call






Buttons on client software window are illustrated in the following figure.



The keys on Client software are correspond to some keys on the computer keyboard. This is illustrated in the following picture:



Functions:

- Press  to go off hook and dial or to send digits dialed from Keyboard.
- Press  to answer an Incoming Call
- Press  twice to redial the last number Dialed
- Press  to Hang Up.
- Press Handfree key on the set to active hands free function
- Press C on the phone to cancel the number you dialed
- Press  on the phone to show

contact list

- Press ▲/▼ on the phone to roll the

Phonebook

Click the phone book button on the client software to open the phonebook pad.

Add /Delete contacts

Click the button "+" to add, enter the information and click OK. Or click the button "-" to delete

Modify contact

Double click the contact, or right click and choose "Modify", and make changes, click "OK" to save

Calling a contact using the Phonebook

Open the phonebook and click on the contact you want to call and click the right button to choose the phone number to call.

Import and export phonebook

Point the Mouse to the phonebook display window, click right key and choose import or export phone book.

Import methods: Import from Outlook or CSV file. (Comma Separated Value, a text file where fields are delimited by commas)

list

Export methods: Export to CSV file. This file can then be used by other applications.

NOTE: For KU1500A once the Phonebook has been installed it will be resident in computer.

Call History

Click "History" button, then click "All Calls", "Called", "Answered Calls" or "Missed Calls" to view the corresponding call history. You may also "Right Click" on any item to move it into your Phonebook.

Call back

Choose the number from the list and click "call back" button, then click "Call/Accept Call" button to dial out.

Use * to Correct a Number

The * key can be used as "backspace" key to allow you correct misdialed numbers.